



Make and Model	Year	Shock Model					Part Number	Note
		Hyper X	Sport X	Hyper Lite	Sport Lite	Classic		
BMW								
R45	1978-1985			•		SL600300	Requires + 20 eye	
R60/5/6/7	1969-1984	•		•		SX600335, SL600335		
R65 LS	1978-1985	•		•		SX600300, SL600300	Requires + 20 eye	
R75/5/6/7	1969-1987	•		•		SX600335, SL600335		
R80 RT/7	1970-1987	•		•		SX600335, SL600335		
R90	1973-1987	•		•		SX600335, SL600335		
R100	1970-1987	•		•		SX600335, SL600335		
DUCATI								
250 Single	1964-1976			•		SL400300	Requires +10 eye	
350 Single	1965-1976			•		SL400300	Requires +10 eye	
450 Single	1969-1974			•		SL400300	Requires +10 eye	
500 Sport	1972-on			•	•	HL400335, SL400335		
500 Pantah	1978-1985	•	•	•		SX400300, HL400300, SL400300	Requires +10 eye	
600 Pantah	1981-1985	•	•	•		SX400300, HL400300, SL400300	Requires +10 eye	
650 Pantah	1985-1986	•	•	•		SX400300, HL400300, SL400300	Requires +10 eye	
650 Indiana	1986-1987	•		•		SX750335, SL750335	Requires +30 eye	
GT 750 Sport	1972-1975	•		•		SX400300, SL400300	Requires +10 eye	
750 Super Sport	1972-1976	•		•		SX750300, SL750300	Requires +20 eye	
750 Indiana	1987-1990	•		•		SX750335, SL750335	Requires +30 eye	
860 GTS	1985-1979	•		•		SX750335, SL750335		
900 GTS	1975-1979	•		•		SX750335, SL750335		
900 SD Darmah	1978-1984		•	•		HL750335, SL750335		
900 SS	1975-1977			•		SL750300	Requires +20 eye	
900 SS	1978-1984		•	•		HL750335, SL750335		
900 MHR	1979-1984		•	•		HL750335, SL750335		
900 S2 Desmo	1983-1985		•	•		HL750335, SL750335		
1000 S2 Desmo	1983-1985		•	•		HL750335, SL750335		
1000 Biposto Sport	2006-2009	•				HX400335	Requires +40 eye	
GT 1000	2006-2009	•				HX400335	Requires +40 eye	
LAVERDA								
330, 500	1979-1985			•	•	HL400300, SL400300	Requires +30 eye	
750	1970-1980	•	•	•	•	HX750335, SX750335, HL750335, SL750335	Requires +10 eye ∞	
1000	1973-1989	•	•	•	•	HX750335, SX750335, HL750335, SL750335	Requires +30 eye ∞	
1200	1976-1989	•	•	•	•	HX750335, SX750335, HL750335, SL750335	Requires +30 eye ∞	
TRIUMPH								
250 T25	1970-on				•	SC400320	Requires +10 eye	
500 T100	1969-on				•	SC400320		
500 T100C, TR5T	1969-1979				•	SC400320	Requires +10 eye	
650 T120	1963-1970				•	SC400320		
650 TR6	1972-on				•	SC400320		
650 T120R, TR6C, TR6R	1963-1972				•	SC400320	Requires +10 eye	
750 T140	1972-on				•	SC400320		
750 TR7	1972-on				•	SC400320		
750 T150, T160	1969-on				•	SC400320	Requires +10 eye	
Bonneville	2000-on	•	•			HX600335, SX600335		
Bonneville America	2002-on	•	•			HX750300, SX750300	Requires +20 eye	

Speedmaster	2003-on	•	•		HX750300, SX750300	Requires +20 eye
Thruyton	2003-on	•	•		HX600335, SX600335	Requires +30 eye
Thruyton Scrambler	2005-on	•	•		HX600335, SX600335	Requires +30 eye
Thunderbird	2010-on		•		SX850335, SX875335	
Rocket III	2004-on		•		SX875300	Requires +20 eye

∞ Check chain guard clearance.

If your model is not listed please contact us as we may have something to suit.

List updated regularly as more information becomes available.